

Operating Instruction

Hand operated drum pump of Polypropylen

Typ JP-04

1. Installation of the telescopic suction tube

Firmly screw the telescopic suction tube into the female thread of the lower part of the pump body.

Extend telescopic suction tube to required length and firmly thighten wing nut.

2. Commissioning

Fix the hand pump with the male thread, which is on the lower part of the pump body, to your drum. The pump can then be put into operation.

Push handle several times very fast and very strong up and down to build-up water head. A minimum level of 12-15 cm in the container is necessary for the suction process.

Be careful when pumping acids and caustic solutions. Never use this hand operated pump for flammable liquids and solvents or hazard class AI, AII.

Comply to all safety instructions and wear necessary protective clothing (protective, glasses, gloves, apron and possibly boots).



agip POMPE

www.agipompe.com
pompe speciali per l'industria